



Ref#	Numer katalogowy	Description	Qty
1	SP3508-1	Hopper Assembly	1
2	SP3508-2	Big Flat Washer Ø6	16
3	SP3508-3	Hex Bolt M6x40	9
4	SP3508-4	Rivet Ø5x10	2
5	SP3508-5	Swivel Axle Bushing	2
6	SP3508-6	Fixed Adjustable Plate	1
7	SP3508-7	Active Adjustable Plate	1
8	SP3508-8	Hex Bolt M6x20	3
9	SP3508-9	Base for Torsion Spring	1
10	SP3508-10	Nylon Lock Nut M6	21
11	SP3508-11	Torsion Spring	1
12	SP3508-12	Flat Washer Ø8	2
13	SP3508-13	Fix Plate for Connecting Rod	1
14	SP3508-14	Nylon Lock Nut ,M8	2
15	SP3508-15	Hex Bolt M6x35	7
16	SP3508-16	Teeth Lock Washer Ø8	1
17	SP3508-17	Crossover Tube	1
18	SP3508-18	Swivel Axle Fix Plate	1
19	SP3508-19	Frame Tube Assembly	1
20	SP3508-20	Cotter Pin Ø5x35	1
21	SP3508-21	Flat Washer Ø16	7

22	SP3508-22	Pneumatic Wheel	2
23	SP3508-23	Wheel Axle Bushing	2
24	SP3508-24	Inner Axle Bushing	2
25	SP3508-25	Outer Axle Bushing	2
26	SP3508-26	Swivel Axle	1
27	SP3508-27	Pinion Gear	1
28	SP3508-28	Swivel Axle Base	1
29	SP3508-29	Gear (Driver)	1
30	SP3508-30	Wheel Axle	1
31	SP3508-31	Pin Ø4x30	1
32	SP3508-32	Nylon Lock Nut M5	2
33	SP3508-33	Inner Hex Bolt M5x45	1
34	SP3508-34	Pin Ø3x16	1
35	SP3508-35	Screw M4x20	1
36	SP3508-36	R Pin Ø3	2
37	SP3508-37	Impeller	1
38	SP3508-38	Brace Hitch	2
39	SP3508-39	Hitch Tube	1
40	SP3508-40	Hitch Bracket	1
41	SP3508-41	Pin Ø12x65	1
42	SP3508-42	Hex Bolt M6x25	2
43	SP3508-43	Carriage Bolt M6x25	1
44	SP3508-44	Spacer	1
45	SP3508-45	Wing Nut	1
46	SP3508-46	Nylon washer	1
47	SP3508-47	Handle Grip	1
48	SP3508-48	Adjustable Handle	1
49	SP3508-49	Connect Rod	1
50	SP3508-50	Gauge Plate	1
51	SP3508-51	Adjustment Rod	1
52	SP3508-52	Hopper Screen	1
53	SP3508-53	Hex Bolt M5 x 40	1
54	SP3508-54	Rain Cover	1

